



Operating instructions [ENG](#)



Operating instructions [SLO](#)

Basic

12Vdc, 4 digital inputs, 2 relay outputs, DC power supply and accumulator voltage remote checking, SM

Advance

12Vdc, 8 digital inputs, 1 analog input, 2 relay outputs, 1 digital output, I2C interface, DC power supply

Reference

12Vdc, 8 digital inputs, 2 analog inputs, 2 relay outputs, 2 digital outputs, RS232/RS485 serial interface