



Operating instructions [ENG](#)



Operating instructions [SLO](#)

Basic

12Vdc, 2 digital inputs, 1 relay output, DC power supply and accumulator voltage remote checking, SMS

Advance

12Vdc, 4 digital inputs, 1 relay output, 1 digital output, I2C interface, DC power supply and accumulator

Reference

12Vdc, 4 digital inputs, 1 relay output, 1 digital output, RS232/RS485 serial interface, I2C interface, DC