



Operating instructions [ENG](#)



Operating instructions [SLO](#)

### **Basic**

12Vdc, 2 digital inputs, 1 relay output, DC power supply and accumulator voltage remote checking, SMS

### **Advance**

12Vdc, 4 digital inputs, 1 relay output, 1 digital output, I2C interface, DC power supply and accumulator

### **Reference**

12Vdc, 4 digital inputs, 1 relay output, 1 digital output, RS232/RS485 serial interface, I2C interface, DC