



Operating instructions [ENG](#)



Operating instructions [SLO](#)

### **Basic**

12-30Vdc, 8 digital inputs, SMS alarming and programming, quad-band GSM module with SIM card holder

### **Advance**

12-30Vdc, 8 digital inputs, 4 digital outputs, 4 relay outputs, 4(6) analog inputs, interface to connect 3 terminals

### **Reference**

12-30Vdc, 8 digital inputs, 4 digital outputs, 4 relay outputs, 4(6) analog inputs, interface to connect 3 terminals